RESMED

Fitting Guide



 Prior to fitting the mask, remove the elbow from the mask by pressing the squeeze-tabs.



 Connect the elbow to the device air tubing.



 With both lower headgear straps released, hold the mask against the face and pull the headgear over the head.



 Bringing the lower straps below the ears, loop the headgear into the lower hooks on the mask frame.



 Unfasten the straps, pull the upper headgear straps evenly until they are comfortable and firm, and reattach the straps.



 Repeat step 5 with the lower headgear straps.



 Attach the combined elbow assembly and air tubing to the mask by pressing the squeeze-tabs and pushing into mask frame.

• Turn on the airflow device.

Pair the Mirage FX with ResMed's S9™ for an exceptionally quiet, comfortable system that fits your patients' lifestyles.



Mirage[™] FX
NASAL MASK

ResMed.com

ResMed Corp San Diego, CA, USA +1 858 836 5000 or 1 800 424 0737 (toll free). ResMed Ltd Bella Vista, NSW, Australia +61 (2) 8884 1000 or 1 800 658 189 (toll free). See ResMed.com for other ResMed locations worldwide. SoftEdge and Spring Air are trademarks of ResMed Ltd. Mirage and S9 are trademarks of ResMed Ltd and are registered in the U.S. Patent and Trademark Office. ©2011 ResMed. Specifications may change without notice. 1014520/2 11 03